

Driver Safety

Mirrors:

- Adjust your rearview mirror so that you can see the entire rear window from the driver's seat.
- Adjust the driver's side mirror by placing your head against the left window and setting the mirror so that you can barely see the side of your vehicle.
- Adjust the passenger-side mirror by positioning your head just above the center console and setting the mirror so that you can barely see the passenger side of your vehicle.
- Use different types of mirrors to see blind spots, such as convex, front-mounted, or backing devices.
- Recognize the limitations concerning the distance of objects in mirrors.
- Use mirrors every 5 – 7 seconds and before lane changes, merges, turns, and backing.
- Know your vehicle's blind spots.
- Adjust and maintain mirrors regularly.